Fixed
LCD/ PLASMA Wall Mount
Premium Series

Assembly instructions

50

⚠ CAUTION - This Mount is intended for use only with the maximum weight as indicated. Using heavier products, might cause injury.

Fits Up to	Max	
	US	EU
56" 142cm LCD/Plasma	132lbs	60kg

110050.2 31.12.09

Barkan Mounting systems *A better point of view™*

For further information, visit us at:
www.barkanmounts.com

1:5

A

x2

B



x2

C

x2

1:1

D

x4

E

x4

1:2

F



x1

G

sticker

Releasing and locking

For Model 51 - Before releasing/ locking align screen with wall.

To release - move screen right.

To lock - move screen left.

x1

M

The provided M bolts may change in size according to the evolution of screen market requirements



Please make sure that package contains all parts

Tools Required



1





1 rail



2 rails



2

H=115mm/4.5"







3A Find stud, Level & Mark left rail



Drill





Find stud, Level & Mark right rail




4A
Drill
A
D
F
Force
5


3B
Level & Mark right rail
A
H
Drill
STOP
DANGER
Ø6mm (1/4")
80 mm (3")
1
Ø10mm (3/8")
80 mm (3")
2


The anchor must be sunk up to 10 mm(3/8") into the plaster coating
10mm (3/8")
Plaster coating
E
A
D
F
4B
1
2
X min 4 max 9
X2

4B Level & Mark right rail



Drill







5 Test!

















Dear customer, we welcome your comments and suggestions to improve our products, ease of assembly and instructions. Please contact us via our website: **www.barkanmounts.com**